

## **SPASS**

## Άδεια εισόδου χειριστή

Serves the identification of the welder and the protection of the FRIAMAT electrofusion units (only documentation units) against unauthorised access. The data stored in the fusion pass (welder number or welder's name) are transmitted to the fusion record.

To order, please download the application form from www.aliaxis.de in the product catalogue under Welder's Pass.



Κωδικός προϊόντος	Weight kg
623100	0,010

