

# Electrofusion coupler

The electrofusion couplers are delivered with centre stops. These stops can easily be removed with a knife or screwdriver (200, 250, 315), so that the coupler can be used as a slide-coupler. Before welding, cut pipe ends squarely with a pipe cutting tool, remove the oxide film with a scraper and mark the insertion depth. The couplers can easily be welded with our Akatherm control box and other suitable control boxes.

